Mold & Prolonged Humidity Microbial Losses: Pack-Out Sequencing & Cross-Contamination Containment

Canonical Web Version: https://restorationintel.com/mold-prolonged-humidity-microbial-losses-pack-out-sequencing/

Direct Answer: Microbial pack-out sequencing requires clearing or sealing Condition 1 areas first, isolating Condition 2 and 3 rooms under 6-mil poly containment and negative-pressure HEPA filtration, HEPA-vacuuming and encapsulating restorable items before exit, and keeping dirty loads quarantined from clean warehouse vaults.

Field Benchmark & Decision Matrix

Workflow Stage	Zone Status	Engineering / Barrier Control	Custody & Packaging Rule	Crew Hygiene / PPE Gate
1. Condition 1 Pre-Clearance	Condition 1 (Clean)	Positive/isolated from affected wing; HVAC locked out	Standard clean cartons & pad-wrap; load into clean truck or safe room	Clean workwear; zero dirty boots or tools inside zone
2. Containment & Airlock Build	Boundary Setup	6-mil poly walls, zipped doorways, HEPA AFD vented outside or scrubbed	Verify negative pressure via manometer or flutter strip before entry	Stage PPE donning/doffing station outside airlock
3. In-Zone Pre-Cleaning & Wrap	Condition 2 / 3 (Dirty)	Continuous HEPA scrubbing; zero dry sweeping or shaking	HEPA-vac loose spores off hard exteriors; double-bag or 6-mil wrap & tape	Fit-tested P100 respirator, hooded Tyvek, eye seal, double gloves
4. Airlock Pass-Through Transfer	Decon Chamber	Two-stage zippered chamber between dirty zone and clean hallway	Damp-wipe exterior of sealed poly/totes inside airlock; hand to clean runner	Dirty crew stays inside; clean runner stays outside airlock
5. Non-Salvageable Disposal Exit	Condition 3 Waste	Dedicated waste route; keep path swept/HEPA-vac'd post-exit	Double-bag 6-mil waste bags (gooseneck tape seal) after photo/adjuster sign-off	Doff outer boot covers & coveralls upon exiting dirty cycle
6. Transport & Warehouse Intake	Quarantine Bay	Dedicated microbial box truck or sealed poly-lined trailer bulkhead	Unload directly into negative-pressure microbial processing bay, never main vault	HEPA-vac & wipe truck deck, dollies, and blankets post-delivery

Practitioner Operational Takeaways

• Secure or pack out Condition 1 rooms before breaching Condition 2/3 containment barriers whenever site layout allows.


• Construct 6-mil poly containment with a two-stage airlock and verify inward negative pressure using a HEPA-filtered AFD.

• Enforce OSHA 1910.134 fit-tested respirators and OSHA 1910.132 PPE with two-team dirty/clean airlock handoffs.

• HEPA-vacuum loose spores, wrap restorable goods in sealed 6-mil poly or wipeable plastic totes, and damp-wipe exteriors at the airlock.

• Transport microbial lots in segregated vehicles directly to a negative-pressure warehouse quarantine bay, never shared clean storage.

Visual Workflow & Benchmark Summary



Companion Endpoints & Verified Primary Sources

• **Markdown Twin (plain text):**
https://restorationintel.com/mold-prolonged-humidity-microbial-losses-pack-out-sequencing.md

• **ANSI/IICRC S520 Mold Remediation Standard:** https://iicrc.org/s520/

• **ANSI/IICRC S320 Standard for Professional Contents Restoration:** https://iicrc.org/s320/

• **OSHA 1910.134 Respiratory Protection Standard:**
https://www.osha.gov/laws-regs/regulations/standardnumber/1910/1910.134

• **OSHA 1910.132 Personal Protective Equipment Standard:**
https://www.osha.gov/laws-regs/regulations/standardnumber/1910/1910.132